

IMPORTANT - DECLARATIONS & WARNINGS

All Barn Light Australia lighting products are designed to be assembled, installed, and finished by a fully-licensed Electrician.

For outdoor ratings to be valid, junctions between the mounting surface and the luminaire must be sealed using supplied gaskets, with an outdoor-rated, UV Resistant silicon used on the mounting surfaces.

Broke something? Might have lost parts? - Call Barn Light. We've got spares.
If you believe any facet, part, or component is damaged - Call Barn Light.
We're here to make your job easier, both now and in the future.

IMPORTANT - LEFT-HANDED THREADED HEX COUPLER




WAREHOUSE SHADES


1. Remove "Elec 25mm" Electrical Assembly from marked bag.
2. Remove Terminal Block.
3. Turn Hex Coupler **Clockwise** to remove the Hex Coupler
4. Ensure O-Ring Gasket is kept within the Hex Coupler, re-seat if necessary.
5. Thread wire through centre of Warehouse Shade.
6. Thread wire through Hex Coupler with O-Ring facing towards the shade.
7. Tighten the Hex Coupler down by rotating **Anti-Clockwise** until hand-tight.

COMPONENTS

SHADES



ATOMIC



**CAUTION: READ ALL INSTRUCTIONS PRIOR TO ASSEMBLY.
INSTALLATIONS BY QUALIFIED ELECTRICIANS ONLY**

ATOMIC ONLY

1. Remove Terminal Block
2. Release grub screw using 3mm Alley Key
3. Thread electrical through mounting (ensure the use of thread-tape/silicon)
4. Counter-Rotate 3-4 turns (off the thread) to allow for tangled wires.
5. Rotate **Anti-Clockwise** onto threads of mounting, until hand-tight.
6. Tighten Grub Screw using 3mm Allen key.

ATOMIC - IF USING A WAREHOUSE SHADE

1. Remove Terminal Block
2. Turn Hex Coupler **Clockwise** to remove the Hex Coupler
3. Ensure O-Ring Gasket is kept within the Hex Coupler, re-seat as necessary.
4. Thread wire through centre of Warehouse Shade.
5. Thread wire through Hex Coupler with O-Ring facing towards the shade.
6. Tighten the Hex Coupler Down by rotating **Anti-Clockwise** until hand-tight.

FOR ATOMIC UNITS (Post Install - Glass & Guard)

1. Ensure Large O-Ring is seated within the threads (ships pre-installed).
2. Install E27 Globes as necessary (supplied where purchased from Barn Light)
3. Rotate Glass **Anti-clockwise** to affix internal threads to Atomic unit.
4. Rotate selected guard (cast/wire) onto the external threads of Atomic unit.
5. Tighten grub screw if necessary (not applicable to wire guards) to prevent removal.